



Mustang Canister Purge Solenoid Harness Installation Instructions

These Instructions Cover the Following Part Numbers:

FH-034 1987-1993 Ford Mustang Canister Purge Solenoid Harness

Installation Instructions:

- 1) Disconnect battery
- 2) While paying attention to how original harness is routed, disconnect old harness at Canister Purge Solenoid and main harness connections. Pay particular care not to break off the connector locks at the main harness connection.
- 5) Install new harness.
- 6) Complete installation by confirming harness is routed away from exhaust and any moving parts.

Wire Works Enterprises Inc
T/A Ron Francis Wiring
200 Keystone Rd.
Chester, PA 19013
800-292-1940
www.ronfrancis.com

Warranty Information

All Ron Francis Wiring products are warranted for 1 year from purchase date. There are no other representations, warranties or conditions expressed or implied, statutory or otherwise except those herein contained. Warranty does not cover any defect which is the result of improper installation or modification of the system or any of its components by purchaser.

Ron Francis Wiring, its dealers or agents will not be liable, in any way, for any damage, loss, injury or other claims, resulting from the use or misuse, or inability to use any of our products. Purchaser and/or user, assumes liability of any kind connected with the use and/or application of our products.

Copyright © 2006 Ron Francis Wiring