


TO GET MAXIMUM LIGHT FROM THESE BULBS

RON FRANCIS

WIRING

B-2337

Headlight Bulbs

 **BR** TM **ITE**
BULBS

Wire the **brighter** filament for LOW beam. Install a jumper wire from the low beam wire on the dimmer switch to the 'hot' side of the switch. This will allow the low beam to stay on *with the* HIGH beam, thus producing maximum light. Alignment is extremely important for maximum illumination. These bulbs are not legal in some states and the user shall need to determine this before use. If using our harness, hook blue to red wire at the dimmer switch.

