

RON FRANCIS WIRING

MC-62

**Brite Lights-Red
Lens Original Bullet**

Installation: A 1/2 inch hole is required for mounting the light. After drilling the mounting holes, make sure there is a clean, paint-free area around the hole in order to get a good ground. Run the tan and white wires through the center of the mounting bolt and tighten securely.

Wiring: The tan wires are the dim filament and the white wires are the bright filament. The tan wire is run to parking/running light wire and the white wire to turn signal/brake light wire.

Bulb replacement part number: WIRE WORKS part number B-1005

NOTE!

Mounting this unit upside down requires sealing the area around where the wires exit the unit with **HIGH TEMPERATURE SEALANT** to prevent internal damage. Failure to perform this procedure will cause the unit to fail prematurely.