

**RON FRANCIS**  
*Wiring*

**BRIT LITES**

**Chrome  
Rounded End**

Red Lens

Installation: A 1/2 inch hole is required for mounting the light. After drilling the mounting holes make sure there is a clean, paint free area around the hole in order to get a good ground. Run the tan and white wires through the center of the mounting bolt and tighten securely. **Wiring:** The tan wires are the dim filament and the white wires are the brite filament. The tan wire is run to parking/running light wire and the white wire to turn signal/brake light wire. Bulb replacement part number is RON FRANCIS WIRING part number B-1005.

**NOTE!**

Mounting this unit upside down requires sealing the area around where the wires exit the unit with **HIGH TEMPERATURE SEALANT** to prevent internal damage. Failure to preform this procedure will cause the unit to fail prematurely.