

**RON FRANCIS**

*Wiring*

**PD-18**

**Power Door  
Opening Solenoids  
Feed Wire**

**\* \* \* \***

The wire supplied is for the 12 volt feed to switches and on to your door solenoids. Follow the manufacturer's instructions for circuitry and hookup locations.

**\***

Wire Works is continually changing and improving products. These instructions are written in conjunction with wiring kits in production now. If you have an older Panel, you may find that references to certain numbers and colors between the kits may not agree. You will need to call us with the serial number on your wiring kit and inform us of your needs, we will give you conversion numbers to make things happen.