

Mount the shift indicator in the dash board as desired, OR until aligned, you may wish to keep 000000 the indicator lights in sight from under the car to speed setup. Park & Neutral use a yellow light, Reverse uses a red light, "O" uses the blue light and the rest of the forward gears use green lights. A 12 volt ignition feed must be supplied to the red wire in the gray cable.

in the following order: Park to Lt. Green wire, Reverse to White wire, Neutral to Black wire, Overdrive to Yellow wire, Drive to Orange wire, Second to Lt. Blue wire. Low to Brown wire. The Ground for the indicator lights is done by tying all the yellow (or black) wires together and running them to a good ground.

Connect the red wires from each indicator light