



This plate blocks off the factory Ford EGR Valve Position Sensor located on the EGR spacer plate located between the upper plenum and throttle body.

It is necessary to either "chip" or fool the ECM to think the EGR is disabled or codes will set and your engine will not operate at its best. FORDFUELINJECTION.COM offers an EGR eliminator that will plug into the EGR Valve Position Sensor connector and give the ECM a reading it wants to see.

This unit is not intended for pollution controlled vehicles. For off road use only.